

```
'-----Title-----
' File.....16F877A_hpwm1.pbp
' Started....1/17/08
' Microcontroller used:  Microchip Technology 16F877A
'                          microchip.com
' PicBasic Pro Code:  micro-Engineering Labs, Inc.
'                          melabs.com

'-----Program Description-----
' Uses HPWM command to set the motor speed
' of a motor.  The HPWM command works in the
' background while two LEDs blink.

'-----Schematic-----
' See schematic at:
' http://www.cornerstonerobotics.org/schematics/pic16f877a\_hpwm1.pdf

'-----Related Lesson-----
' hpwm1.pbp (the 16F88 program) is used in
' the lesson MOTOR CONTROL WITH PWM at:
' http://www.cornerstonerobotics.org/curriculum/lessons\_year2/erii21\_motor\_control\_pwm.pdf

'-----New PicBasic Pro Commands-----
' The PicBasic Pro Compiler Manual is on line at:
' http://www.microengineeringlabs.com/resources/index.htm#Manuals
'
' HPWM Channel,Dutycycle,Frequency
'
' Outputs a PWM signal using the PICs hardware which
' is available on some PICs including the PIC16F877A.
' The HPWM Channel 1 (CCP1) for the PIC16F877A is RC2.
' The HPWM Channel 2 (CCP2) for the PIC16F877A is RC1.
' The Dutycycle ranges from 0 (0%) to 255 (100%).
' For the PIC16F88, the frequency ranges from 245Hz
' to 32,767 Hz.
' Look around page 75 in the PicBasic Pro Compiler Manual
' The frequency of 245 Hz seems to work best for the
' Jameco #155855 gearhead motor.

'-----Revisions-----
' 1/5/09      Change MCU from 16F88 to 16F877A

'-----Variables-----

      c0 VAR  BYTE          ' BYTE to store counter variable

'-----Initialization-----
```

```
TRISB = %00000000    ' Sets all pins of PORTB as outputs

ADCON1 = %00000110   ' Changes PORTE and PORTA analog bits to
                    ' digital operation since not using ADC
                    ' (Analog to Digital Converter)

'-----Main Code-----

    HPWM 1,127,245    ' Format: HPWM Channel,Dutycycle,Frequency
                    ' Motor is driver by Channel 1, (RC2) on
                    ' the PIC16F877A. Channel 2 would be RC1.
                    ' The Dutycycle is set at 127,
                    ' sending a 50% duty cycle pulse.
                    ' The frequency is set for 245 Hz.
                    ' This command will continue to run
                    ' in the background while the program is
                    ' executing the rest of the program
                    ' instructions.

start:                ' This part of the program makes the LEDs blink.

    FOR c0 = 1 TO 5
    HIGH 1
    LOW 2
    PAUSE 100
    LOW 1
    HIGH 2
    PAUSE 100
    NEXT c0

    FOR c0 = 1 TO 2
    HIGH 1
    LOW 2
    PAUSE 500
    LOW 1
    HIGH 2
    PAUSE 500
    NEXT c0

    GOTO start

END
```